## **Energy Matters pump controller/maximiser**

The Energy Matters pump motor maximiser (also known as an optimiser) is available in 6 amp / 12 amp and 12 volt / 24 volt configurations.

Any number of additional level sensors can be connected in parallel (open type) On/Off Switch When the switch closes, the pump will be turned off. Float switch (if optionally fitted) must be a normally open type switch. If your switch is normally closed, turn it upside down. Connect switch in parallel with the on/ off switch using the Solar panel Pump motor connection strip screw connection connection terminals.



## **Energy Matters**

63-69 Market Street South Melbourne Victoria AUSTRALIA 3205

installation.

P: +61 3 9697 1900 F: +61 3 9997 1919

NOTE: terminals inside

controller may not be in the same location as shown;

always check the labels on

the terminals at the time of

E:sales@energymatters.com.au W: www.energymatters.com.au

## Installation

Version date 17/4/10

Energy Matters provide this wiring diagram for installation as a recommendation and guide for the installation of equipment. It is to used by experienced and competent users/installers only. Energy Matters cannot be held responsible for any equipment, property, or person damaged or injured as a result of improper installation.